



Emerge[™] 1000

Installer/User Guide



**INSTRUCTIONS**

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**DANGEROUS VOLTAGE**

This symbol is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

**PROTECTIVE GROUNDING TERMINAL**

This symbol indicates a terminal which must be connected to earth ground prior to making any other connections to the equipment.



Emerge[™] **1000**

Installer/User Guide

Avocent, the Avocent logo, The Power of Being There and EmERGE are trademarks or registered trademarks of Avocent Corporation or its affiliates. All other marks are the property of their respective owners.

© 2005 Avocent Corporation. All rights reserved. 590-549-501A

USA Notification

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his/her own expense.

Canadian Notification

This digital apparatus does not exceed Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.

Japanese Approvals

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Safety and EMC Standards

EN55022 Class A, EN55024, EN 61000-3-2, EN 61000-3-3, EN60950, FCC 47CFR Part15 Class A, CSA C22.2 No. 60950, IEC 60950, FCC 15 Class A, UL 60950 third edition, VCCI Class A

TABLE OF CONTENTS

Chapter 1: Product Overview	1
<i>Features and Benefits</i>	<i>1</i>
<i>Compatibility with Peripherals.....</i>	<i>1</i>
<i>Safety Precautions</i>	<i>2</i>
Chapter 2: Installation	3
<i>Getting Started.....</i>	<i>3</i>
<i>Mounting options</i>	<i>3</i>
<i>Connecting the local keyboard, monitor and mouse</i>	<i>3</i>
<i>Connecting power.....</i>	<i>6</i>
Chapter 3: Operations	7
<i>About Your Emerge 1000 Extender</i>	<i>7</i>
<i>Configuring keyboard layout and emulation for the receiver</i> <i>via the OSD.....</i>	<i>8</i>
<i>Configuring keyboard layout and emulation for the transmitter</i> <i>via the OSD.....</i>	<i>8</i>
<i>Configuring your OSD hotkey sequence.....</i>	<i>9</i>
<i>Activating OSD Timeout.....</i>	<i>9</i>
<i>Displaying system information</i>	<i>9</i>
<i>Upgrading Your ECMS1000R Receiver and Transmitter</i> <i>via Bootloader.....</i>	<i>11</i>
<i>Activating bootloader</i>	<i>12</i>
<i>Bootloader features</i>	<i>13</i>
Appendices.....	19
<i>Appendix A: Technical Specifications</i>	<i>19</i>
<i>Appendix B: Technical Support</i>	<i>21</i>
<i>Appendix C: Troubleshooting.....</i>	<i>22</i>

Product Overview

Features and Benefits

The *Emerge*[™] 1000 extender, which utilizes the ECMS1000R receiver and an AMIQDM module (transmitter), allows PS/2 and USB keyboard, video and mouse (KVM) peripherals to work seamlessly from up to 1000 feet away from your server. Standard UTP cabling makes installation simple and keeps costs low. The ECMS1000R receiver can be rack mounted, desk mounted or mounted on the back of your monitor.

Its industry-standard design makes the *Emerge* 1000 extender compatible with virtually any PC, display technology and operating system. Installation requires no new drivers or software.



Figure 1.1: ECMS1000R Receiver

Compatibility with Peripherals

The *Emerge* 1000 extender is compatible with the following peripherals:

- Keyboard - The *Emerge* transmitter and receiver support standard PS/2 and USB keyboards.
- Mouse - The *Emerge* transmitter and receiver support 2-button PS/2 and USB mice. Mice that have more than two buttons work with the reduced functionality of a 2-button mouse.
- Video - The *Emerge* 1000 extender supports VGA, SVGA, XGA and UXGA resolutions up to 75 Hz refresh rate. Both CRT and LCD monitors with standard 15-pin high density connectors are supported.

- Audio - Speakers are supported on the receiver side of your *Emerge* 1000 extender, provided the transmitter has been connected to the sound card of your PC with the provided audio cable.

Safety Precautions

To avoid potential video and/or keyboard problems:

- If the building has 3-phase AC power, ensure that the server and monitor are on the same phase. For best results, they should be on the same circuit.

To avoid potentially fatal shock hazard and possible damage to equipment, please observe the following precautions:

- Do not use a 2-wire extension cord in any product configuration.
- Test AC outlets at the server and monitor for proper polarity and grounding.
- Use only with grounded outlets at both the server and monitor. When using a backup Uninterruptible Power Supply (UPS), power the server and the transmitter off the same supply.

NOTE: The AC inlet is the main disconnect.

Installation

Getting Started

Before installing your *Emerge* 1000 extender system, refer to the list below to ensure that you have all the items necessary for installation.

Needed for the *Emerge* 1000 extender system

- ECMS1000R receiver (supplied)
- System specific AMIQDM module (sales option dependent, contact Avocent)
- External Power Supply (supplied)
- IEC power cord (supplied)
- *Emerge* 1000 Quick Installation Guide (supplied)

Mounting options

The ECMS1000R receiver features the following mounting options, allowing you to easily adapt to most work environments:

- Under desk mounting via the horizontal mounting bracket
- Monitor mounting via the mounting plate accessory
- Rack mounting via the rack mount kit

NOTE: Mounting accessories are ordered separately. Contact Avocent for more information.

Connecting the local keyboard, monitor and mouse

The following instructions will enable you to connect your *Emerge* 1000 extender system.



WARNING: To reduce the risk of electric shock or damage to your equipment -
Disconnect the power from the extender by unplugging the power supply from the electrical outlet.

To connect the ECMS1000R receiver:

1. Select a convenient location for your ECMS1000R receiver.
2. Plug your keyboard, monitor and mouse cables into the appropriate ports on the back of the ECMS1000R receiver.
3. Insert one end of a UTP cable into the LINK port on the rear of the ECMS1000R receiver.
4. Route the UTP cable to the AMIQDM module at the remote server, up to 1000 feet (300 meters) away and connect them together.




Figure 2.1: ECMS1000R Receiver and AMIQDM Module Installation

To connect the AMIQDM module:

1. Power down the remote server.
2. Connect the AMIQDM module keyboard, monitor and mouse connectors to the appropriate ports on the back of the server.
3. Connect the AMIQDM module serial and audio connectors into the appropriately labeled ports on the back of the server, if desired.
4. Power up the server.




Figure 2.2: PS/2 AMIQDM Module

Connecting power

The ECMS1000R receiver features an external power supply with a 4-pin miniDIN connector. A DC port is located on the rear of the ECMS1000R receiver.

NOTE: Use only an Avocent-supplied power supply.

To connect power to the ECMS1000R receiver:

1. Plug the external power supply's 4-pin miniDIN connector into the DC port on the ECMS1000R receiver.
2. Connect the detachable IEC power cord into the power supply.
3. Plug the IEC power cord into an appropriate wall outlet.

About Your *Emerge* 1000 Extender

While the default settings on your *Emerge* 1000 extender will work with most systems, you may choose to change settings to better fit your extender system. Internal settings such as keyboard layout, emulation and hotkey sequences can be configured via the On-Screen Display (OSD), while Flash upgrades are available via the bootloader function. The OSD also displays your system settings and information about your connected transmitter.

NOTE: Table 3.1 lists available hotkey options to access the OSD.




Figure 3.1: Configuration Screen

Configuring keyboard layout and emulation for the receiver via the OSD

To change your keyboard layout and/or emulation:

1. Activate the OSD by pressing the hotkey sequence. If you are activating the OSD for the first time, any of the sequences in Table 3.1 will activate the display. Ensure the Config tab is selected.

Table 3.1: OSD Hotkey Sequences

Hotkey Sequences (all sequences are default until selected)	
Print Screen	Alt - Alt (L)
Ctrl - Ctrl (L - R)	Alt - Alt (R)
Ctrl - Ctrl (L)	Shift - Shift (L - R)
Ctrl - Ctrl (R)	Shift - Shift (L)
Alt - Alt (L - R)	Shift - Shift (R)
Scroll - Scroll	

2. Click the *Local* radio button to change keyboard settings for the ECMS1000R receiver.
3. Use the Layout drop-down menu to scroll to and select your desired country.
4. Select the type of keyboard you are using from the Emulation drop-down menu. The ECMS1000R receiver supports standard, Chyron Duet and Pinnacle FAK keyboard emulation.
5. Click *Apply* to save settings, or click *Close* to exit without saving changes.

Configuring keyboard layout and emulation for the transmitter via the OSD

To change your keyboard layout and/or emulation:

1. Activate the OSD by pressing the hotkey sequence. Ensure the Config tab is selected.
2. Click the *Remote* radio button to change settings for the remote transmitter.
3. Use the Layout drop-down menu to scroll to and select your desired country. The PS/2 AMIQDM supports standard and Pinnacle FAK. The Emulation drop-down menu is greyed out if a USB or Sun AMIQDM is attached to the receiver and the Remote radio button is selected.

Configuring your OSD hotkey sequence

To change the hotkey sequence that activates your OSD:

1. Activate the OSD by pressing the default or your currently configured hotkey sequence. Ensure the Config tab is selected.
 2. Select your desired hotkey sequence from the OSD Hotkey drop-down menu.
- The following table lists selectable hotkey sequences available to activate the OSD.

Activating OSD Timeout

The ECMS1000R receiver can be configured to log out users after 15 minutes of inactivity.

To activate OSD Timeout:

1. Activate the OSD by pressing the hotkey sequence. Ensure the Config tab is selected.
2. Click the *OSD Timeout* checkbox at the bottom-left corner of the screen.

Displaying system information

To display system information:

1. Activate the OSD by pressing the hotkey sequence.
2. Click on the *Info* tab.
3. Click the *Local* radio button for information about the ECMS1000R receiver; click the *Remote* radio button for information about the transmitter.

NOTE: The distance between the ECMS1000R receiver and remote transmitter is shown at the bottom of the screen.




Figure 3.2: Local System Information



Figure 3.3: Remote System Information




Figure 3.4: No Device Connected

Upgrading Your ECMS1000R Receiver and Transmitter via Bootloader

The *Emerge* 1000 extender system can be upgraded through the serial port. All terminal commands are accessed through a terminal or PC running HyperTerminal[®] emulation software or equivalent.

To access the Terminal Applications menu:

Connect a terminal or PC running terminal emulation software to the serial port on the back panel of the ECMS1000R receiver using a null modem cable. The terminal should be set to 57600 baud, 8 data bits, no parity, 1 stop bit and no flow control.




Figure 3.5: Com1 Properties

Activating bootloader

To activate bootloader:

1. Activate the OSD by pressing the hotkey sequence. Ensure the Config tab is selected.
2. Click the *Invoke* checkbox in the bottom-right corner of the screen.
3. Click the *Call* button.

The screen closes and the ECMS1000R receiver bootloader OSD is displayed. The terminal menu is now available on the serial port.




Figure 3.6: Bootloader Menu: No Connected Device




Figure 3.7: Active Bootloader Menu

Bootloader features

You can select several bootloader options using the terminal menu keyboard.

Resetting the ECMS1000R receiver from the terminal menu

Once bootloader is active, you can exit the menu and reset the device by typing **0**.




Figure 3.9: OSD During XMODEM Update

NOTE: Figure 3.9 will display during an XMODEM update via the serial console of the ECMS1000R receiver. The boot and application codes must be updated separately using the XMODEM. The percentage complete shows the amount for the file being transferred.

Transmitter boot and application upgrade via XMODEM

Option 2 allows you to program the boot and application of the connected transmitter. The update file has to be sent via XMODEM from the terminal software after this option is chosen.




Figure 3.10: Upgrade Transmitter Boot or Application Code

The OSD screen in Figure 3.11 will appear when a connected transmitter is being updated. Up to three files (boot, application and/or FPGA) can be sent to the transmitter. The update release notes will say which files are needed. Always update the boot code before the application. The percentage bar displays the percentage complete for a particular file.




Figure 3.11: Updating a Local Transmitter

Transmitter FPGA upgrade via XMODEM

Option 3 allows you to program the FPGA code of the connected transmitter. The update file has to be sent via XMODEM from the terminal software after this option is chosen. See Figure 3.12.





Figure 3.12: Upgrade Transmitter FPGA

Displaying information about connected devices

Type ? to display the System Information of the connected transmitter.



```
ECMS1000R - HyperTerminal
File Edit View Call Transfer Help

=====
=== AVOCENT ECMS1000R Bootloader 1.0.3.3 (4.0.1.8) FPGA[1.1.2.0]
=== ECMS1000R [03 0B 10 001708 40 45]
=== Port 1 [01 0F 10 019655 10 10]
=====

1) ECMS1000R flash upgrade via XMODEM
2) Transmitter [01 0F 10 019655 10 10] application upgrade via XMODEM
3) Transmitter [01 0F 10 019655 10 10] FPGA upgrade via XMODEM
0) Reset device
?) Display information about connected device

Your choice: ?

Port 1 [01 0F 10 019655 10 10] Phonak
Hardware Rev: B
Firmware Rev: 4. 0. 5. 0
Firmware Rev: 4. 0. 2. 0
FPGA Rev: 2. 0. 8. 0

-

Connected 0:07:38 Auto detect 57600 8-N-1 SCROLL CAPS NUM Capture Print echo
```

Figure 3.13: Transmitter Information Screen

APPENDICES

Appendix A: Technical Specifications

Table A.1: *Emerge 1000 Extender Product Specifications*

Extension Ports	
Number	1
Connectors	RJ-45 switch interconnect
User Ports	
Number	PS/2: 1; USB: 1 (with two connectors); Serial: 1; VGA video: 1
Type	PS/2, USB and VGA video
Connectors	6-pin miniDIN, PS/2 keyboard and mouse; USB Type A, USB keyboard and mouse; 15HDD female; VGA; 9-pin D-Shell, Serial; 3.5mm audio jacks, line out and mic
Dimensions	
H x W x D	27 x 210 x 188 mm (1.06 x 8.27 x 7.40 in)
Weight	1Kg (2.20 lb) without packaging, cables, power supply and literature
Heat Dissipation	90 K
Power Consumption	25 W
AC-input power	25 W maximum
AC-input current rating	A
AC-frequency	50/60 Hz
Temperature	0° to 40° Celsius (32° to 104° Fahrenheit) operating -20° to 50° Celsius (-4° to 122° Fahrenheit) nonoperating
Humidity	0 to 95% noncondensing operating
Supported Hardware	
Peripherals	PS/2 keyboard and mouse, USB keyboard and mouse, speakers, microphone, serial devices (max baud rate of 38,400 baud)
Video Resolution	1280 x 1024 with 1000 feet of UTP from server to user; 1600 x 1200 with 100 feet of UTP from server to user

Table A.1: *Emerge* 1000 Extender Product Specifications (Continued)

Supported Hardware	
Sync Types	Separate horizontal and vertical; sync on green (as used on SGI and HP9000); composite
Safety and EMC Standards	EN55022 Class A, EN55024, EN 61000-3-2, EN 61000-3-3, EN60950, FCC 47CFR Part15 Class A, CSA C22.2 No. 60950, IEC 60950, FCC 15 Class A, UL 60950 third edition, VCCI Class A

Appendix B: Technical Support

Our Technical Support staff is ready to assist you with any installation or operating issues you encounter with your Avocent product. If an issue should develop, follow the steps below for the fastest possible service.

To resolve an issue:

1. Check the pertinent section of this manual to see if the issue can be resolved by following the procedures outlined.
2. Check our web site at www.av.avocent.com to search the knowledge base or use the on-line service request.
3. Call the Avocent Technical Support location nearest you.

Appendix C: Troubleshooting

Table C.1: Troubleshooting the ECMS1000R Receiver

No power status light on ECMS1000R receiver
Verify that the power supply is plugged in correctly.
Ensure that the power cable from the Avocent-supplied power supply is securely plugged into the ECMS1000R receiver.
No video on monitor attached to ECMS1000R receiver
Verify that the monitor attached to the ECMS1000R receiver has power.
Ensure that the video cable from the monitor is securely plugged in to the correct connector on the ECMS1000R receiver.
Ensure that the video cable from the AMIQDM module is securely plugged in to the correct connector on the server.
Verify that the server is powered.
Cycle power to the ECMS1000R receiver. An informational message should appear on the monitor for a brief moment. If the message does not appear, check the monitor by plugging the video cable from the monitor directly into the server to verify that the monitor is working and that the server is generating active video. If this is functioning, check that the display settings for your server are set no higher than a resolution of 1024 x 768 at 60 Hz refresh rate. If the monitor does not function correctly, replace it.
As a last check, plug the video cable from the monitor directly into the server to verify that the monitor is working and that the server is generating active video. If this is functioning, check that the display settings for your server are set no higher than a resolution of 1024 x 768 at 60 Hz refresh rate. If the monitor does not function correctly, replace it.
No mouse or keyboard operation from peripherals attached to ECMS1000R receiver
Ensure that the mouse and keyboard operation cables are connected to the correct PS/2 or USB ports on the ECMS1000R receiver. Match the connector color codes (green is mouse and purple is keyboard).
Ensure that the mouse and keyboard cables from the AMIQDM module are connected to the correct PS/2 or USB ports on the server. Match the connector color codes (green is mouse and purple is keyboard).
Retest the mouse and keyboard by connecting them directly to the server and rebooting. If one does not function correctly, replace the nonfunctioning peripheral.

Table C.1: Troubleshooting the ECMS1000R Receiver (Continued)

No audio from speakers attached to ECMS1000R receiver
Ensure that the audio cable is securely plugged into the line out port of the server (should be color-coded green).
Ensure that the speaker cable is securely plugged into the line out port of the ECMS1000R receiver.
Retest the speakers by connecting them directly to the server. If they do not function correctly, replace them.
Ensure speakers are powered.
Poor video quality on monitor attached to ECMS1000R receiver
Ensure that the video cable from the monitor is securely plugged in to the correct connector on the ECMS1000R receiver.
Ensure that the video cable from the AMIQDM module is securely plugged in to the correct connector on the server.



Avocent

The Power of Being There®

For Technical Support:

www.avocent.com/support

Avocent Corporation
4991 Corporate Drive
Huntsville, Alabama 35805-6201 USA
Tel: +1 256 430 4000
Fax: +1 256 430 4031

Avocent Asia Pacific
Singapore Branch Office
100 Tras Street, #15-01
Amara Corporate Tower
Singapore 079027
Tel: +656 227 3773
Fax: +656 223 9155

Avocent Canada
20 Mural Street, Unit 5
Richmond Hill, Ontario
L4B 1K3 Canada
Tel: +1 877 992 9239
Fax: +1 877 524 2985

Avocent International Ltd.
Avocent House, Shannon Free Zone
Shannon, County Clare, Ireland
Tel: +353 61 715 292
Fax: +353 61 471 871

Avocent Germany
Gottlieb-Daimler-Straße 2-4
D-33803 Steinhagen
Germany
Tel: +49 5204 9134 0
Fax: +49 5204 9134 99

590-549-501A